

# ASSEMBLY INSTRUCTIONS

## Description: Windsor Accent Chair






### Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.


### Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

### Parts List

Item	Description		QTY
P1	Front Legs		2
P2	Back Legs		2
P3	Chair		1
P4	Seat cushion		1
P5	Back cushion		1

### Hardware List


Item	Description		QTY
H1	Plastic washer		4

### DISCLAIMER:


WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

### Assembly Procedures:


Step 1. Remove the seat cushion and take out the legs and hardware under the seat.



Step 2. Turn the chair upside down and lay on protective carpet. Screw in the feet (P1&P2) into the screw holes underneath the base using the plastic washers (H1).



Step 3. Turn the assembled chair to an upright position. Put the seat cushion ( P4)and the back cushion(P5) on it. Assembly is complete.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase