



ASSEMBLY INSTRUCTIONS

Description: Samba Accent Chair




Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.






Pre-assembly:


- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

Item	Description	QTY
P1	Chair Body 	1
P2	Front Legs  (P2)	2
P3	Back Legs  (P3)	2

Hardware List

Item	Description	QTY
H1	Short Bolts $\text{Ø}1/4 \times 2$ " 	4
H2	Long Bolts $\text{Ø}1/4 \times 2-1/2$ " 	4
H3	Lock Washers $\text{Ø}1/4$ " 	4
H4	Flat Washers $\text{Ø}1/4$ " 	4
H5	Allen Wrench $\text{Ø}1/4$ " 	1




DISCLAIMER:

WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

Assembly Procedures:

Step 1: Assemble the chair on a flat and soft surface either on a carpet or cloth to prevent the finish from scratching. Attach the front legs (P2) and back legs (P3) to the bottom of chair body (P1) as shown.

- (H1)x4 Short Bolts $\text{Ø}1/4 \times 2$ " 
- (H2)x4 Long Bolts $\text{Ø}1/4 \times 2-1/2$ " 
- (H3)x8 Lock Washers $\text{Ø}1/4$ " 
- (H4)x8 Flat Washers $\text{Ø}1/4$ " 
- (H5)x1 Allen Wrench $5/16$ " 



Step 2. Turn the assembled chair to an upright position. Make sure the chair is level and securely tighten all bolts with Allen wrench (H5).

Leveler adjustment: Leveler are pre-installed on the legs and adjust as needed to make sure the chair is level. Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**

ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase