




### Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.





### Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

### Parts List

Item	Description	QTY
P1	Front legs 	2
P2	Back legs 	2
P3	Chair top 	1

### Hardware List


Item	Description	QTY
H1	Bolts 5/16"x 25mm 	12
H2	Lock Washers 5/16" 	12
H3	Flat Washers 5/16" 	12
H4	Allen Wrench 	1

### DISCLAIMER:





WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.


### Assembly Procedures:

**Step 1:** Assemble the chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Remove the legs and hardware package from the chair.





**Step 2:** Attach front leg (P1) and back legs (P2) to chair top (P3) using Lock washers (H2), Flat washers (H3) and Bolt (H1) as shown below.

- (H1)x12 Bolts 5/16"x 25mm 
- (H2)x12 Lock Washers 5/16" 
- (H3)x12 Flat Washers 5/16" 
- (H4)x1 Allen Wrench 



**Step 3:** Turn the assembled chair to an upright position. Assemble is complete.



Note: Front legs can be adjusted with adjustable levelers.

**ADDITIONAL NOTE ABOUT SAFETY:**  
**BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE.**  
**THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY, AND ENSURE STABILITY.**

Thank you for your purchase