


Rectangle dining table

style # TG249-TA03
dpci # 249-04-3120



>> assembly instructions



Congratulations on your latest Target purchase.

Now what? Don't start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you'll be on your way to transforming your room in no time. Good luck ---- though we're confident you won't need it.

Before you begin

1. Check for damaged or missing parts. Call 1-855-MY TGT HOME (1-855-698-4846) to order missing supplies.
2. Use the carton as a working surface to prevent product damage during assembly.
3. Gather all tools prior to assembly.

Contents of dining table


introduction	2
parts list	4
assembly	5 - 8

QUESTIONS?


Just call 1-855-MY TGT Home (1-855-698-4846) parts and service. For faster service, have the style number and DPCI number ready when calling.

Hardware


(H1) x 8
Long Bolt (5/16" x 3-1/2")




(H2) x 14
Short Bolt(5/16" x 1")




(H3) x 22
Lock Washer



(H4) x 22
Flat Washer




(H5) x 1
Hex Wrench




ITEM DESCRIPTION QUANTITY

A	Top panel	1
B	Mounting plates	2
C	Legs	4
D	Bottom frame	1



Note: Do not tighten these bolts at this step.



Step 1.

Assemble the dining table on a soft, scratch-free surface such as a carpet or a rug. Loosely attach 4 legs(C) to the bottom frame(D) using bolts(H1), lock washers(H3), flat washers(H4) and hex wrench(H5).

(H2) x 4
Short Bolt
(5/16" x 1")




(H3) x 4
Lock Washer




(H4) x 4
Flat Washer



(H5) x 1
Hex Wrench



Caution: Make sure the label "Top" face up.



Step 2.

Attach the mounting plates(B) to the assembled leg frame by using bolt(H2), lock washer(H3), flat washer(H4) and hex wrench(H5). Make sure the legs are level and securely tighten these four bolts.

(H2) x 10
Short Bolt
(5/16" x 1")





(H3) x 10
Lock Washer



(H4) x 10
Flat Washer



(H5) x 1
Hex Wrench



Caution: Please see the bolt size on the hardware package. Be careful not use long bolt "H1" to attach the table top or it could case damage to your table top.

Step 3.

Turn the table top upside down on a soft, scratch-free surface. Attach the assembled base on the top panel by using short bolt(H2), lock washer(H3), flat washer(H4) and hex wrench(H5) as shown. Securely tighten all bolts.

