

IMPORTANT Warnings and Safeguards

READ INSTRUCTIONS CAREFULLY

As with all electrical products, misuse of product or failure to properly follow the instructions may cause overheating, fire, or personal injury. Please read the product label and all of the instructions before using your warming product.

Welcome

The use of this Automatic Product will give you maximum comfort.

The "safety watch™" controller is the latest technology for safety and temperature control of warming products.

We know you will enjoy this product for years to come.

IMPORTANT INSTRUCTIONS DO NOT DESTROY WE RECOMMEND THAT YOU KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE READ CAREFULLY BEFORE USING THIS PRODUCT

1

Control and Setup information

AUTOMATIC THROWS

Control Model #: EE-CT-10-WS-03-TW (For use only with Throw model # EE-TW-10-WS)

Features:

- PATENTED "SAFETY WATCH™" CONTROLLER - insures safety and assured performance
- AUTO-OFF –approximately 2 hour independent auto-off (Reference shut off time may vary base on product)
- 3 TEMPERATURE SETTINGS –select your personal comfort zone
- SILENT OPERATION –no clicking
- EASY GRIP -ergonomic control for easy operation
- LED INDICATORS – easy viewing the setting you have selected

When the power switch is pressed the controller's three green indicator lights (LED), next to the setting button, will cycle through a quick self- test and then start operation in the Low setting. You may now use the Setting switch to adjust the throw to your desired setting. During the initial heat-up period and continuously thereafter, the controllers' internal computer makes numerous safety and diagnostic tests. If a problem is detected, the power to the Throw heating circuit is turned off and the controller's three LED Indicators will flash. When all three of the indicators are flashing, an error condition has been detected by the controller's Safety watch function. In normal operation, you should only see one of the three LED indicators on at any given time. This will also indicate what setting you have selected. If the controller LED indicators are flashing, do the following:

1. Turn off the controller power switch.
2. Be certain that the cord from the controller to the Throw is plugged in securely to the Throw.
3. Lay out the Throw flat, not bunched up, and with no cover.
4. Wait 30 minutes.
5. Turn the controller back on.
6. If the controller LED indicators are still flashing, call 1(866)-456-8852 for further technical assistance.

Auto-off Feature:

The "Auto-Off" feature is designed for safety and conservation of energy by automatically turning your warming product off after 2 hours of continuous use. The Auto-off function engages 2 hours from the time the control is turned "On".

To restart after a power failure:

Press the "On/Off" or "On" button, the warming product will return to the low setting and begin to warm. In some instances, your safety watch function may cause the three indicators to flash, indicating an error condition, when the throw is powered back on. If this happens, follow the steps 1 through 6 above to reset your controller.

Note: After a power outage, the "Auto-off" feature resets the timer.

NOTE: Remember this warming product is not a heating pad. It will not feel hot to the touch when used in its normal manner.

CAUTION: Do not allow this controller to be covered with pillows, blankets or any other object.

CAUTION: Always turn Warming Throw controller OFF and UNPLUG when not being used.

- 1.) Use only with 110-120 Volt AC 60 Hz wall outlet as provided in the USA and Canada. Do not use with power supplied by an inverter or generator such as in an RV, or a converter outside of the USA and Canada. Do Not use with Extension Cords.
- 2.) Do not fold when in actual use, this may cause excessive heating. **WARNING:** Bunching, folding or covering this throw while in use may cause dangerous overheating. **BEFORE THE FIRST USE and after each wash, lay the throw flat on a hard surface and follow the internal wire track with your hand to verify the internal wiring has not been twisted during packaging, shipping or washing process. If twisted internal wiring is found please contact JLA Home Customer service at 1-866-456-8852 before using this product.**
- 3.) Do not use this warming product with an infant, a child under 12, an immobile person, an incapacitated person, a paraplegic, a quadriplegic, a diabetic, one insensitive to heat, or anyone who cannot clearly understand the instructions and/or operate the controls.
- 4.) Do not use with damaged cords. Damaged cords can lead to fire. Do not trap, fold, cross, or pinch cords between bed slats, mattress, or springs, or against walls, footboards or bed frame.
- 5.) Do not dry clean this warming product. Cleaning liquid may damage the insulation of the heating element. Improper laundering may cause problems with the heating wire, which can become a fire hazard. (Refer to specific care instructions on next page).
- 6.) Do not tuck in the wired area of this Throw.
- 7.) Do not use this **Throw** with rocking chairs, recliners, chairs with casters or wheels, or other furniture subject to movement that may cause the cord to be pinched.
- 8.) Do not use on a waterbed, bunk bed or a mechanically adjustable bed.
- 9.) Do not cover this warming throw with another blanket or throw, or anything down filled.
- 10.) **Never put the controller under the throw, a cushion or cover the controller vents with any other object;**
- 11.) **Always turn off and unplug the controller(s) for this warming product when not in use.**
- 12.) Keep control away from drafty areas that may become damp such as an open window.
- 13.) **Do not use this warming throw with dogs, cats, or any other pets. This is an electrical appliance that they can damage by chewing or scratching. If this item is returned with pet hair on it, the Warranty is Automatically Voided.**
- 14.) Do not use pins; they may damage electric wiring.
- 15.) Do not use another electronic heating device, such as a heating pad in conjunction with your warming product.
- 16.) If the "Important Instructions" section is not followed, the warming product will not operate properly or safely.
- 17.) Wrapping cords around the controller may damage the cord. Loop cords loosely when storing.
- 18.) After reviewing all set up information and trouble shooting guide, if you see the warming product operating improperly, unplug it immediately and call **E&E CO.Ltd.** Customer Service at: **1-866-456-8852**
- 19.) **This item must be washed before returning to E&E CO.Ltd. for any type of inspection after use of the product by consumer.**

2

Quick Set Up – Warming Throw

WARNING: FAILURE TO FOLLOW THESE INSTRUCTIONS EXACTLY COULD INCREASE THE RISK OF THROW OVERHEATING, FIRE, OR PERSONAL INJURY.

CAUTION: Never allow the Throw controller to be covered up. The controller contains electric components that generate heat. Covering the controller could cause the controller to overheat and create a fire hazard.

CAUTION: Do not plug warming Throw main power cord into the wall outlet until you have completely set up the warming Throw per these instructions.

CAUTION: Never use a controller unit with this warming Throw other than the one supplied with this Throw.

CAUTION: Always make sure the power cord is disconnected from the wall outlet whenever you connect or disconnect your warming Throw from its control.

CAUTION: Always make sure cords are NOT trapped or pinched by any portion of the furniture in which you are using it on. Refer to page 2 for specifics about where and where not to use this product.

1. Place the warming Throw over your body with the label side facing outward. The warming Throw must lay as **FLAT** as possible on top of your body. It is acceptable to tuck the (edges only) of the Throw under your legs or body. Never allow the heating portion (wired areas) of the Throw to be bunched up or tucked into the Furniture. Never cover the Throw with another blanket or throw or any Down filled item. Do not use this Throw in conjunction with any other heating device (such as a heating pad).



DO NOT TUCK



DO NOT COVER




DO NOT FOLD OVER

CAUTION: Not having the warming throw laying **FLAT** and **UNCOVERED** by other bedding articles increases the risks of overheating and possible fires.

2. Plug cord from controller into the module at the bottom of the warming Throw until the plastic lock clicks into place. **DO NOT** attempt to force the plug. The plug module is intended to fit in only one direction. If the plug does not fit into the module, reverse the plug.

CAUTION: Cord **MUST** be **COMPLETELY CONNECTED**. A risk of overheating and fire could result from a loose connection.



3. Run the cord over the floor to the nearest 110-120 Volt wall outlet. Never tuck the cord or the controller unit into any part of the furniture being used. Avoid any tangling or pinching of the cord.

4. Plug the warming throw main power cord into a 110-120 volt 60 HZ wall outlet.

CAUTION: Do not use with an inverter such as in a RV or use with a converter outside of the US or Canada. Do not use in a wall outlet that has been damaged or is worn. A bad connection between the main power cord and the wall outlet may increase the risk of overheating and fire.

CAUTION: This appliance has a polarized plug (one blade is wider than the other) as a safety feature. This plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

Turn on the warming blanket controller's power switch.. Upon turning on the power switch, the controller's three LED indicators should cycle through a brief self test, and then stop with only the Low position Indicator on. If a problem is detected, all three LED indicators will flash continuously indicating an ERROR. If this occurs the power to the heating element is not turned on. The LED should not flash under normal operation, but should stay on continuously. If the LED is flashing, refer to the "FEATURES" section of the Automatic Throw control and setup information page. Using the Setting switch, you can now set the desired heat setting.

CAUTION: Always turn Warming Throw controller OFF and UNPLUG when not being used.

3

4

TROUBLESHOOTING FOR YOUR AUTOMATIC THROW


This is a new and more advanced control than what is on the market. If you experience trouble getting your warming product to operate, follow these troubleshooting instructions carefully.

1. This electronic controller device has the on/off button marked with a circle with the line thru it as indicated below or printed as on/off on the button.

ON/OFF BUTTON



2. After turning on the control, the Three LED Indicators should cycle through a self test and then stop with only the Low position LED on. At this time, the setting switch can be used to select the desired heat setting L-M-H.
3. If turned off during operation and an attempt is made to turn back on immediately you may occasionally see all three LED indicators flashing at the same time, this indicates that an Error has been detected by the Safety Watch Function. If this situation occurs, turn the control back off for a minimum time of 30 minutes and then restart the control.
4. If the error condition continues, then it may be necessary to reset the controls. To do this, turn the control off; unplug the control from the wall outlet and allow the control and the Throw to cool all the way down, no less than 30 minutes is recommended by the manufacturer. Then plug the control back into the wall outlet and turn the control on. See if the LED indicators cycle through the self test and then stop with the Low indicator on. At this point adjust desired temperature using the temperature setting button.
5. The warming product will automatically turn itself off after 2 hours of continued use. (Reference shut off time may vary base on product)
6. If the problem continues, please call our [Customer Service toll free number 1\(866\) 456-8852](tel:18664568852).
7. It may be a little snug when it's unplugged. Some force may be required when attempting to press the release button that allows you to disconnect the cord from the warming product.
8. On high, the warming product will heat approximately 15 degrees F, above the ambient room temperature.



5

Frequently Asked Questions

Q. Who should NOT use the warming product?
A. UL recommends that the following people should NOT use the warming product:

- An infant
- A child, under 12 years old
- An incapacitated person
- A paraplegic
- A quadriplegic
- A diabetic
- Anyone insensitive to heat
- Anyone who cannot clearly understand the instructions or operate the controls.

Q. What do the Underwriters Laboratories (UL) or (ETL) labels mean? What does either of these labels mean about safety of this E&E CO.Ltd. product(s)?

A. Underwriters Laboratories (UL) develops product safety standards for a large range of products and performs independent tests based on these standards. Products tested by UL and which have passed all the safety standards are permitted to bear the UL label. Intertek Testing Services (ETL) is a certified, independent testing organization that tests products in accordance with UL safety standards and issues the ETL label for those products that meet the relevant UL standards. All E&E CO.Ltd. products are tested to UL standards and bear either the UL or ETL label to indicate that the product meets or exceeds UL/ETL safety standards for warming products.

Q. I have heard that some warming products have Electromagnetic Fields (EMF's). What is this?

A. EMF stands for Electromagnetic Field. This is an electrical field that surrounds any wire that has current flowing along its length. Although several studies have been conducted to evaluate the impact, **EMF's have not been proven to be harmful.** In any event, E&E CO.Ltd. has reduced the strength of EMF's in its blankets to very low levels.

Q. What do I do if my pet chews the cord, I lose my controller or the controller does not operate properly?

A. Please stop using the warming product immediately. Call our Consumer Service number listed under "How to Obtain Warranty Service" and ask for instructions on how and where to send the warming product.

Q. My controller feels warm to the touch: Is this a problem?

A. No. The control will feel warm to the touch when functioning properly.

Q. I have experienced some shedding of the fabric fibers of my warming product, what do I do?

A. Follow the use and care instructions to wash and dry your warming product.

Q. My warming product doesn't heat properly.

A. Check to make sure the cord is plugged into the module and the power cord is firmly connected to the wall outlet. Check that the control is "On". If the system still fails to heat, try the following test to see if it is operating:

- Fold the warming product over 3 times.
- Connect the control to the module and plug the power cord into an outlet.
- Turn the control to the highest setting and wait five to seven minutes.
- Put your hand between the folds and you should feel the product warming.

NOTE: Remember the warming product is not a heating pad. It will not feel hot to the touch when laid out flat in a normal manner.

CAUTION: DO NOT continue the test for more than seven minutes. **DO NOT** attempt to make any internal adjustments to this appliance. If you have tried all of the solutions above and the warming product still doesn't work, stop using it immediately, disconnect the power cord and contact our customer service number at 1-866-456-8852

NOTE: If this product or any component has been tampered with in any fashion, the warranty is automatically voided.

7

Care & Cleaning

The care and cleaning of your warming product is easy and safe as long as you follow a few simple steps.

Caution: Always disconnect the power cord and the warming product connection cord at the warming product end before washing. Carefully follow all washing instructions or your warming product may shrink and possibly cause a fire hazard.

DO NOT

- DO NOT dry clean your warming product. Dry cleaning solvents may damage the warming product.
- DO NOT use bleach or cleaning fluids.
- DO NOT use a wringer.
- DO NOT iron the warming product.
- DO NOT use mothballs or sprays of any kind.
- DO NOT turn the warming product on until it is completely dry.

MACHINE WASHING:

Wash separately in automatic washer using slow agitation and normal spin speed:
Fill washer with cold or lukewarm water. Add minimum amount of all-purpose detergent, agitate to dissolve before adding throw. Add throw and soak 5 minutes. Agitate 2 minutes and spin. With throw still in machine, fill for cool rinse, agitate 1 minute and spin.

MACHINE DRYING:

Preheat the dryer on the low temperature setting for 2 minutes. Dry in automatic dryer on medium to low temperature and tumble dry for 5 minutes only, or air dry. Remove damp throw from dryer, block to original size, and drape to finish drying.

DO NOT USE CLOTHESPINS.

DO NOT IRON THIS THROW.

HAND WASHING:

Presoak the warming product for 15 minutes in mild soap and lukewarm water.

Gently squeeze the soapsuds through a few times.

Rinse in fresh, cold or lukewarm water.

HAND DRYING:

Gently stretch / block (re-shape) the throw back to its original size.

Air dry by draping over a clothesline or hang over a shower rod.

DO NOT USE CLOTHESPINS.

DO NOT IRON THIS THROW.

Caution: DO NOT USE commercial dryers or the dryers at your local Laundromat. They get too hot and would damage the warming circuits of the warming product.

Caution: Warming Product MUST BE COMPLETELY DRY BEFORE USING

6

Warranty

E&E CO.Ltd. warrants that for a period stated below from the date of purchase, this product will be free from defects in material and workmanship. This warming product manufactured by E&E CO.Ltd. will carry a FIVE year limited warranty. E&E CO.Ltd., at its option, will repair this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty. This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. E&E CO.Ltd., or any retail stores selling the E&E CO.Ltd. products do not have the right to alter, modify, or any way change the terms and conditions of this warranty.

This warranty does not cover normal wear of parts or damage resulting from any of the following negligent use or misuse of the product: use on improper voltage; or current, or use contrary to the operating instructions, disassembly, repair or alteration by anyone other than E&E CO.Ltd.. Further, the warranty does not cover Acts of God, or Nature, such as fire, flood, hurricanes and tornadoes. E&E CO.Ltd. shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty. Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or province to province.

No warranty will be granted without the original receipt, gift receipt or copy thereof.

E&E Co.Ltd . MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, NOT OTHERWISE SPECIFIED HEREIN:

To Obtain Warranty Service

For any questions you may have about your warming product, please contact E&E CO.Ltd. customer service at 1-866-456-8852. You may also wish to write with product questions, or to return your product for repair or replacement:

E&E Co.Ltd.

45875 Northport Loop East
Fremont , CA 94538

To return your product for repair or replacement attach a tag to the product (do not use pins) that includes your name, address, daytime telephone number, and description of the product and problem. Please include a copy of the original sales receipt. Carefully package (clean and pet-hair free) the product. Use UPS or parcel post, with shipping and insurance prepaid.

DO NOT RETURN THIS PRODUCT TO THE PLACE OF PURCHASE.

8